ASSUMPTION UNIVERSITY

FACULTY OF ENGINEERING COMPUTER ENGINEERING



CE4224 TELECOMMUNICATION NETWORK LABORATORY SECTION 641 SEMESTER 2/2022

WEEK4 WIRELESS NETWORK CONFIGURATION

SUBMITTED TO: A. Sneha Paudel

SUBMITTED BY: Mr. Senee Suksawat ID: 6235107

DATE: 2022/12/21

Introduction

Wireless network configuration encompasses several potential variances across environments. Even in a complex single site, the network configuration basics required for a successful implementation can vary from one wireless network to another running on the same hardware as part of the overall wireless LAN environment.

To set up automatic wireless network configuration

- 1. Open Network Connections
- 2. Right-click Wireless Network Connection, and then click Properties
- 3. On the Wireless Networks tab, do one of the following:
- To enable automatic wireless network configuration, select the Use Windows to configure my wireless network settings check box. This check box is selected by default. For information about what happens when you enable automatic wireless network configuration, see Notes.
- To disable automatic wireless network configuration, clear the Use Windows to configure my wireless network settings check box.
- 4. To connect to an existing wireless network, do one of the following:

Access point (infrastructure)

• To connect to an existing access point (infrastructure) network, under Available networks, click the network name, and then click Configure.

In Wireless Network Properties, specify the wireless network key (Wired Equivalent Privacy) settings, or, if the network key is automatically provided for you (for example, the key is stored on the wireless network adapter given to you by your administrator), select the The key is provided for me automatically check box. If you are unsure about whether a network key is needed or which settings you need to enter, contact your network administrator or the wireless network adapter manufacturer.

Important

• If a network does not broadcast its network name, it will not appear under Available networks. To connect to an access point (infrastructure) network that you know is available but that does not appear under Available networks, under Preferred networks, click Add. In Wireless Network Properties, specify the network name (Service Set Identifier) and, if needed, the wireless network key settings.

Computer-to-computer (ad hoc)

• To connect to an existing computer-to-computer (ad hoc) network, under Available networks, click the network name, and then click Configure.

In Wireless Network Properties, specify the wireless network key (Wired Equivalent Privacy) settings, or, if the network key is automatically provided for you (for example, the key is stored on the wireless network adapter given to you by your administrator), select the The key is provided for me automatically check box. If you are unsure about whether a network key is needed or which settings you need to enter, contact your network administrator or the wireless network adapter manufacturer.

If you want to connect to a computer-to-computer (ad hoc) network and both computer-to-computer and access point (infrastructure) networks are within range of your computer, click Advanced, and then click Computer-to-computer (ad hoc) networks only.

- 5. To configure a new wireless network connection, click Add, and then do the following:
- In Wireless Network Properties, specify the network name (Service Set Identifier) and, if needed, the wireless network key settings.
- If the network connection that you are configuring is to a computer-to-computer (ad hoc) network, select the This is a computer-to-computer (ad hoc) network; wireless access points are not used check box.
- 6. To change the order in which connection attempts to preferred networks are made, under Preferred networks, click the wireless network that you want to move to a new position on the list, and then click Move up or move down.
- 7. To change the wireless network connection settings for a network that is listed in Preferred networks, click the wireless network for which you want to change settings, click Properties, and then change the settings as needed.
- 8. To remove a wireless network from the list of preferred networks, under Preferred networks, click the wireless network that you want to remove, and then click Remove.
- 9. To update the list of available networks that are within range of your computer, click Refresh.
- 10. To automatically connect to available networks that do not appear in the Preferred networks list, click Advanced, and then select the Automatically connect to non-preferred networks check box.

Apparatus


- Laptop
- Cisco Packet Tracer

Procedure

- Experiment


Device	Interface	IP Address	Subnet Mask	Default Gateway
PC	Ethernet0	DHCP		192.168.0.1
Wireless Router WRT300N	LAN	192.168.0.1	255.255.255.0	
	Internet	DHCP		
Cisco.com Server	Ethernet0	208.67.220.220	255.255.255.0	
Laptop	Wireless0	DHCP		

- Configure the network following the given topology




- Configure the Wireless Router

a.Create the wireless network on the Wireless RouterClick on the Wireless Router icon on the Packet Tracer Logicalworkspace to open the device configuration window. In the Wireless Router configuration window click on the GUI tab to view configuration options for the Wireless Router.Next, click on the Wirelesstab in the GUI to view the wireless settings. The only setting that needs to be changed from the defaults is the Network Name (SSID). Here, type the name "HomeNetwork" as shown in the figure.



b. Configure the Internet connection on the Wireless Router Click on the Setup tab in the Wireless Router GUI. In the DHCP Server settings verify that the Enabled button is selected and configure the static IP address of the DNS server as 208.67.220.220 as shown in the figure. c. Click on the Save Settings tab.




- Configure the Laptop

Click on the Desktop tab at the top of the Laptop configuration window and select the PC Wireless icon. Once the Wireless-N Notebook Adapter settings are visible, select the Connect tab. The wireless network "HomeNetwork" should be visible in the list of wireless networks as shown in the figure. Select the network, and click on the Connect tab found below the Site Information.




- Configure the PC

Click on the PC icon on the Packet Tracer Logical workspace and select the Desktop tab and then the IP Configuration icon. In the IP Configuration window, select the DCHP radio button as shown in the figure so that the PC will use DCHP to receive an IPv4 address from the Wireless router. Close the IP Configuration window.




- Configure the Internet cloud

Click on the Configtab in the Cloud device window. In the left pane click on Cableunder CONNECTIONS. In the first drop down box choose Coaxial and in the second drop down box choose Ethernet then click the Add button to add these as the From Port and To Port as shown in the figure.



While still in the Config tab click Ethernet under INTERFACE in the left pane. In the Ethernet configuration window select Cable as the Provider Network as shown in the figure.



- Configure the Cisco.com server

Click on the Cisco.com server icon on the Packet Tracer Logical workspace and select the Services tab. Select DHCP from the SERVICES list in the left pane. In the DHCP configuration window, configure a DHCP as shown in the figure with the following settings.

•Click Onto turn the DCHP service on


•Pool name: DHCPpool

•Default Gateway: 208.67.220.220•DNS Server: 208.67.220.220

•Starting IP Address: 208.67.220.1

•Subnet Mask 255.255.255.0

•Maximum number of Users: 50Click Add to add the pool




Configure the Cisco.com server as a DNS server to provide domain name to IPv4 address resolution. Still in the Servicestab, select DNS from the SERVICES listed in the left pane. Configure the DNS service using the following settings as shown in the figure.

•Click Onto turn the DNSservice on

•Name: Cisco.com

•Type: A Record•Address: 208.67.220.220

Click Add to add the DNS service settings




Configure the Cisco.com server Global settings. Select the Configtab. Click on Settingsin left pane. Configure the Global settings of the server as follows:

Select Static

•Gateway: 208.67.220.1


•DNS Server: 208.67.220.220



Click on FastEthernetin left pane of the Config tabConfigure the FastEthernet Interface settings of the server as follows:

•Select Staticunder IP Configuration

•IP Address: 208.67.220.220 •Subnet Mask: 255.255.255.0



- Verify Connectivity


Verify that the PC is receiving IPv4 configuration information from DHCP.

Click on the PCon the Packet Tracer Logical workspace and then the select the Desktoptabof the PC configuration window.

Click on the Command Prompt icon

In the command prompt refresh the IP settings by issuing the commands ipconfig /releaseand then ipconfig /renew. The output should show that the PC has an IP address in the 192.168.0.x range, a subnet mask, a Default Gateway, and DNS server address as shown in the figure.


- Test connectivity to the Cisco.com server from the PC From the command promptissuing the command ping Cisco.com. It may take a few seconds for the ping to return. Four replies should be received as shown in the figure.




Exercise


Device	Interface	IP Address	Subnet Mask	Default Gateway
PC	Ethernet0	DHCP		10.0.0.1
Wireless	LAN	10.0.0.1	255.255.255.0	
Router WRT300N	Internet	DHCP		
Cisco.com	Ethernet0	192.168.0.220	255.255.255.0	
Laptop	Wireless0	DHCP		

- Step 1
Configure the network following the given topology




- Step 2
Set up the network devices by following the information from the addressing table






- Step 3 select the DCHP radio button





- Step 4

select the Connect tab. The wireless network "Network" should be visible in the list of wireless networks.





- Step 5
Configure the Internet cloud







- Step 6 Configure the Cisco.com server










Test the connection



Conclusion

In this week I'm not come to class but lucky that Arjan gave the pdf file in teams, and I have followed it. In this experiment. I have learned about wireless networks, and I also learn about the DHCP and DNS. The DCHP is will automatically understand the IP address on advice. The DNS is like the translator. After I followed the lecture and ask my friends for practice question, it makes me more understand and more get used to, but there are some parts that I don't know like I didn't change the modules of laptop so I cannot connect it at first.